

METER ENCLOSURE SUPPLEMENT – ME1-F-1

Rev A, 2018-07-20

The image below shows an example of how the Meter Enclosure may be set up in the field. Three conduit holes were created at recommended locations, and conduit hubs were installed. Line voltage wires are run through their own conduit hub away from the CT and communications wires for improved safety and to minimize interference. No field-installed wires cross the dashed segregation safety line on the white label.

When setting up an enclosure, create conduit holes only where necessary. Use cable ties and anchor points to keep wiring neat. Extra CT lead wire length may be cut off or bundled.

